


How to automate pump to suction water from lower tank to upper tank using **Flow Switches**.



Useful Links:

- » [Centrifugal Pump Automation and Protection](#)
- » [How it Works: Flow Switches](#)
- » [Increase the life of your Sensor](#)